

GENERAL INFORMATION

1. The combination of highest-precision electronic and mechanical technology heralds a new era in automatic transmission performance.
2. The gear shifting clutches use a hydraulic balancing mechanism to enable gear shifting at extra-high engine speeds.
3. The number of shafts has been decreased to two and increased use has been made of metal plates which all contributes to reduce the weight.
4. Increased meshing ratios and improved rigidity of the gear supports and casing result in less noise.
5. In addition, adoption of a newly-developed automatic transmission fluid (ATF) increases the service life of the fluid.
6. The number of oil cooler feed tubes is increased to two.


Main
Index

23
Index

23D
Index

SECTIONAL VIEW

<F5A51/W5A51>



TFA2159
10TJ049A

- | | |
|--------------------------------|------------------------------|
| 1. Over drive clutch | 13. Torque converter clutch |
| 2. Reverse clutch | 14. Torque converter |
| 3. Overdrive planetary carrier | 15. Input shaft |
| 4. Output planetary carrier | 16. Differential |
| 5. Second brake | 17. Rear cover |
| 6. Low-reverse brake | 18. One-way clutch |
| 7. One-way clutch | 19. Direct clutch |
| 8. Transfer drive gear | 20. Reduction brake band |
| 9. Transmission case | 21. Direct planetary carrier |
| 10. Underdrive clutch | 22. Transfer driven gear |
| 11. Oil pump | 23. Output gear |
| 12. Converter housing | 24. Differential drive gear |

Main
Index

23
Index


23D
Index

HYDRAULIC CIRCUIT

Main Index

23 Index

23D Index



9FA0223
10TJ047A

- | | |
|---|---|
| 1. Reverse clutch | 19. Over drive pressure control valve |
| 2. Low-reverse brake | 20. Reduction pressure control valve |
| 3. Second brake | 21. Torque converter clutch control valve |
| 4. Underdrive clutch | 22. Low reverse solenoid valve |
| 5. Overdrive clutch | 23. Second solenoid valve |
| 6. Reduction brake | 24. Under drive solenoid valve |
| 7. Direct clutch | 25. Over drive solenoid valve |
| 8. Torque converter clutch | 26. Reduction solenoid valve |
| 9. Accumulator | 27. Torque converter pressure control valve |
| 10. Fail safe valve A | 28. Regulator valve |
| 11. Fail safe valve B | 29. Manual valve |
| 12. Fail safe valve C | 30. Oil pump |
| 13. Torque converter clutch control valve | 31. Oil strainer |
| 14. Switch valve | 32. Oil filter |
| 15. Cooler | 33. Oil pan |
| 16. Low reverse pressure control valve | 34. Relief valve |
| 17. Second pressure control valve | |
| 18. Under drive pressure control valve | |

SPECIFICATIONS**GENERAL SPECIFICATIONS**

Items		Specifications
Model		F5A51-2-EZB (2WD) W5A51-1-E1DD (AWD)
Type		Electronically controlled 5-speed full-automatic
Torque converter	Type	3-element with torque converter clutch
	Engine stall speed	2100 – 2600 r/min.
Gear ratio	1st	3.789
	2nd	2.057
	3rd	1.421
	4th	1.000
	5th	0.731
Gear ratio	Reverse	3.865
Final gear ratio		3.684

SERVICE SPECIFICATIONS

Items	Standard value
Output shaft preload mm	0.01 – 0.09
Brake reaction plate end play mm	0 – 0.16
Low-reverse brake end play mm	1.65 – 2.11
Second brake end play mm	1.09 – 1.55
Underdrive sun gear end play mm	0.25 – 0.45
Input shaft end play mm	0.70 – 1.45
Differential case preload mm	0.045 – 0.105
Underdrive clutch end play mm	1.60 – 1.80
Reverse and overdrive clutch return spring end play mm	0 – 0.09
Overdrive clutch end play mm	1.6 – 1.8
Reverse clutch end play mm	1.5 – 1.7
Backlash between differential side gear and pinion mm	0.025 – 0.150
Direct clutch end play mm	1.0 – 1.2

VALVE BODY SPRING IDENTIFICATION TABLE

Spring	Wire diameter mm	Outside diameter mm	Free length mm	Number of loops
Regulator valve spring	1.8	15.7	86.7	24
Underdrive pressure control valve spring	0.7	7.6	37.7	25
Overdrive pressure control valve spring	0.7	7.6	37.7	25
Low-reverse pressure control valve spring	0.7	7.6	37.7	25
Second pressure control valve spring	0.7	7.6	37.7	25
Reduction pressure control valve spring	0.7	7.6	37.7	25
Torque converter valve spring	1.6	11.2	34.4	12.5
Torque converter clutch control valve spring	0.7	5.9	28.1	19
Fail-safe valve A spring	0.7	8.9	21.9	9.5
Damping valve spring	1.0	7.7	35.8	17
Line relief valve spring	1.0	7.0	17.3	10
Orifice check ball spring	0.5	4.5	15.4	15

**Main
Index**

**23
Index**

**23D
Index**

SNAP RING, SPACER, THRUST WASHER, THRUST RACE AND PRESSURE PLATE FOR ADJUSTMENT

**Main
Index**

Thrust washer (For adjustment of input shaft end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.8	18	MD754509	2.4	24	MD753793
2.0	20	MD754508	2.6	26	MD753794
2.2	22	MD754507	2.8	28	MD753795

**23
Index**

**23D
Index**

Snap ring (For adjustment of underdrive clutch and overdrive clutch end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.6	Brown	MD759660	2.4	Blue	MD750845
1.7	None	MD759661	2.5	Brown	MD750846
1.8	Blue	MD759662	2.6	None	MD750847
1.9	Brown	MD758892	2.7	Blue	MD750848
2.0	None	MD750841	2.8	Brown	MD750849
2.1	Blue	MD750842	2.9	None	MD750850
2.2	Brown	MD750843	3.0	Blue	MD750851
2.3	None	MD750844			

Snap ring (For adjustment of low-reverse brake and second brake reaction plate end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
2.2	None	MD756784	2.4	Brown	MD758552
2.3	Blue	MD756785	2.5	None	MD758553

Pressure plate (For adjustment of low-reverse brake end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.6	F	MD759568	2.4	B	MD759428
1.8	E	MD759425	2.6	A	MD759429
2.0	D	MD759426	2.8	0	MD759430
2.2	C	MD759427	3.0	1	MD759431

Pressure plate (For adjustment of second brake end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.6	F	MD759568	2.4	B	MD759428
1.8	E	MD759425	2.6	A	MD759429
2.0	D	MD759426	2.8	0	MD759430
2.2	C	MD759427	3.0	1	MD759431

23D AUTOMATIC TRANSMISSION – Specifications

Main
Index

23
Index

23D
Index

Snap ring (For adjustment of reverse clutch end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.9	None	MD758947	2.4	Blue	MD756694
2.0	None	MD756690	2.5	Brown	MD756695
2.1	Blue	MD756691	2.6	None	MD756696
2.2	Brown	MD756692	2.7	Blue	MD756697
2.3	None	MD756693	2.8	Brown	MD756698

Snap ring (For adjustment of reverse clutch and overdrive clutch spring retainers end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.48	Brown	MD755600	1.58	Blue	MD755602
1.53	None	MD755601	1.63	Brown	MD755603

Thrust race (For adjustment of underdrive sun gear end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.6	–	MD707267	2.2	–	MD723065
1.7	–	MD759681	2.3	–	MD754796
1.8	–	MD723064	2.4	–	MD724358
1.9	–	MD754794	2.5	–	MD754797
2.0	–	MD707268	2.6	–	MD754798
2.1	–	MD754795			

Snap ring (For adjustment of direct clutch end play)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
1.9	Brown	MD758946	2.5	Brown	MD753402
2.0	None	MD753397	2.6	None	MD753403
2.1	Blue	MD753398	2.7	Blue	MD753404
2.2	Brown	MD753399	2.8	Brown	MD753405
2.3	None	MD753400	2.9	None	MD753406
2.4	Blue	MD753401	3.0	Blue	MD753407

23D AUTOMATIC TRANSMISSION – Specifications

Main
Index

Spacer (For adjustment of differential case preload)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
0.83	83	MD756948	1.10	10	MD756957
0.86	86	MD756949	1.13	13	MD756958
0.89	89	MD756950	1.16	16	MD756959
0.92	92	MD756951	1.19	19	MD756960
0.95	95	MD756952	1.22	22	MD756961
0.98	98	MD756953	1.25	25	MD756962
1.01	01	MD756954	1.28	28	MD756963
1.04	04	MD756955	1.31	31	MD756964
1.07	07	MD756956	1.34	34	MD756965

23
Index

23D
Index

Spacer (For adjustment of backlash between differential side gear and pinion)

Thickness mm	Identification symbol	Part No.	Thickness mm	Identification symbol	Part No.
0.56 – 0.64	–	MD757996	0.86 – 0.94	–	MD757999
0.66 – 0.74	–	MD757997	0.96 – 1.04	–	MD758000
0.76 – 0.84	–	MD757998	1.06 – 1.14	–	MD758001

TORQUE SPECIFICATIONS

Items	Nm
Transmission	
Roll stopper bracket	59 – 79
Wiring harness bracket	20 – 26
Control cable bracket	20 – 26
Eye bolt	27 – 33
Oil cooler feed tube	10 – 12
Oil filter	11 – 13
Input shaft speed sensor	10 – 12
Output shaft speed sensor	10 – 12
Manual control lever	19 – 25
Park/neutral position switch (Inhibitor switch)	10 – 12
Speedometer gear	3.9 – 5.9
Valve body cover	10 – 12
Valve body mounting bolt	10 – 12
Fluid temperature sensor	10 – 12
Manual control shaft detent	4.9 – 6.9
Rear cover	20 – 26
Torque converter housing	41 – 53
Oil pump	20 – 26
Transfer drive gear	32 – 36
Output shaft lock nut	157 – 177
Output shaft bearing retainer	20 – 26
Oil filler plug	30 – 34
Oil drain plug	30 – 34
Components	
Differential drive gear	127 – 137
Valve body	10 – 12
Solenoid valve support	5 – 7
Direct planetary carrier lock nut	157 – 177
Anchor plug	83 – 113

SEALANTS









Items	Specified sealant
Rear cover	Mitsubishi genuine sealant Part No. MD974421 or equivalent
Torque converter housing	Mitsubishi genuine sealant Part No. MD974421 or equivalent
Valve body cover	Mitsubishi genuine sealant Part No. MD974421 or equivalent

SPECIAL TOOLS










Main
Index

23
Index

23D
Index

Tool	Tool number and name	Supersession	Application
	MD998333 Oil pump remover.	–	Removal of oil pump.
	MB991629 Spring compressor.	EMB991629.	Measurement of underdrive clutch and overdrive clutch end plays.
	MD998924 Spring compressor re- tainer.		Removal and installation of low-reverse brake snap ring. Measurement of underdrive clutch and overdrive clutch end plays.
	MB990936 Installer adaptor.	–	Installation of differential taper roller bearing outer race.
	MB990938 Handle.	–	Installation of input shaft rear bearing. Use with installer adaptor.
	MB991632 Clearance dummy plate.	–	Measurement of low-reverse brake and second brake end play.
	MD998412 Guide.	–	Installation of oil pump and transfer drive gear.
	MD998334 Oil seal installer.	E9055 (17-010A).	Installation of oil pump oil seal.

23D AUTOMATIC TRANSMISSION – Special Tools





Tool	Tool number and name	Supersession	Application
	MD998800 Oil seal installer.	E21M14A.	Installation of drive shaft oil seal.
	MD998801 Bearing remover.	–	Removal of diff bearings.
	MD998913 Dial gauge extension.	E21M44.	Measurement of low-reverse brake and second brake end plays.
	MD998917 Bearing remover.	–	Removal of direct planetary carrier taper roller bearing.
	MD999590 Spring compressor.	EMD999590.	Removal and installation of overdrive clutch snap ring.
	MD998907 Spring compressor.	E21M43.	Removal and installation of underdrive clutch snap ring.
	MB991630 Spring compressor.	–	Removal and installation of direct clutch snap ring.
	MD998834 Torque wrench adaptor.	–	Removal and installation of direct planetary carrier lock nut.
	MD998823 Installer adaptor (48).	–	Install differential bearings.

Main Index

23 Index

23D Index

23D AUTOMATIC TRANSMISSION – Special Tools

Tool	Tool number and name	Supersession	Application
	MD998812 Installer cap.	–	Use with installer and installer adaptor.
	MD998813 Installer – (100).	–	Use with installer cap and installer adaptor.
	MD998824 Installer adaptor (50)	–	Installation of transfer drive gear.
	MB991633 Reduction brake wrench set.	–	Removal, installation and adjustment of reduction brake piston.

Main Index

23 Index

23D Index

FORM-IN-PLACE GASKET

The transmission has several areas where the form-in-place gasket (FIPG) is in use. To ensure that the gasket fully serves its purpose, it is necessary to observe some precautions when applying the gasket. Bead size, continuity and location are of paramount importance. Too thin a bead could cause leaks. Too thick a bead, on the other hand, could be squeezed out of location, causing blocking or narrowing of the fluid feed line. To eliminate the possibility of leaks from a joint, therefore, it is absolutely necessary to apply the gasket evenly without a break, while observing the correct bead size.

DISASSEMBLY

The parts assembled with the FIPG can be easily disassembled without use of a special method. In some cases, however, the sealant between the joined surfaces may have to be broken by lightly striking with a mallet or similar tool. A flat and thin gasket scraper may be lightly hammered in between the joined surfaces. In this case, however, care must be taken to prevent damage to the joined surfaces.

SURFACE PREPARATION

Thoroughly remove all substances deposited on the gasket application surfaces, using a gasket scraper or wire brush. Check to ensure that the surfaces to which the FIPG is to be applied is flat. Make sure that there are no oils, greases and foreign substances deposited on the application surfaces. Do not forget to remove the old sealant remaining in the bolt holes.

FORM-IN-PLACE GASKET APPLICATION (FIPG)

When assembling parts with the FIPG, you must observe some precautions, but the procedure is very simple as in the case of a conventional pre-cut gasket. Applied FIPG bead should be of the specified size and without breaks. Also be sure to encircle the bolt hole circumference with a completely continuous bead. The FIPG can be wiped away unless it is hardened. While the FIPG is still moist (in less than 15 minutes), mount the parts in position. When the parts are mounted, make sure that the gasket is applied to the required area only. In addition, do not apply any oil to the sealing locations or start the engine until a sufficient amount of time (about one hour) has passed after installation is completed. The FIPG application procedure may vary on different areas. Observe the procedure described in the text when applying the FIPG.


TRANSMISSION

DISASSEMBLY AND REASSEMBLY

Main
Index

23
Index


23D
Index



TFA2175
10TJ050A

- 1. Torque converter
- 2. Roll stopper bracket
- 3. Harness bracket
- 4. Control cable support bracket
- 5. Oil level gauge
- 6. Eye bolts
- 7. Cooler pipes


- 8. Input shaft speed sensor
- 9. Output shaft speed sensor
- 10. Manual control lever
- 11. Park/neutral position switch
- 12. Speedometer gear
- 13. Valve body cover
- 14. Manual control shaft detent



TFA2175
10TJ050A

- 15. Fluid temperature sensor
- 16. Valve body
- 17. Steel ball
- 18. Gasket
- 19. Snap ring
- 20. Solenoid valve harness
- 21. Strainer
- 22. Second brake retainer oil seal
- 23. Accumulator piston

- 24. Accumulator spring
- 25. Accumulator spring
- 26. Snap ring
- 27. Accumulator cover
- 28. Accumulator spring
- 29. Accumulator piston
- 30. Manual control lever shaft pin
- 31. Manual control lever shaft
- 32. Parking pawl rod



Lubricate all internal parts with automatic transmission fluid during reassembly.

TFA2176
10TJ051A

- | | |
|--------------------------------------|--------------------------------|
| 33. Torque converter housing | 52. Parking roller support |
| 34. Differential | 53. Direct planetary carrier |
| 35. Oil filter | 54. Anchor plug |
| 36. Oil pump | 55. Direct clutch |
| 37. Gasket | 56. Reduction brake band |
| 38. Pipe | 57. Thrust bearing #11 |
| 39. Thrust washer #1 | 58. Thrust race #12 |
| 40. Under drive clutch & input shaft | 59. Rear cover |
| 41. Thrust bearing #2 | 60. Thrust race #8 |
| 42. Under drive clutch hub | 61. Seal ring |
| 43. Snap ring | 62. Input shaft rear bearing |
| 44. Reduction brake piston cover | 63. Accumulator piston |
| 45. Snap ring | 64. Accumulator spring |
| 46. Reduction brake piston | 65. Thrust bearing #7 |
| 47. Reduction brake spring | 66. Reverse & overdrive clutch |
| 48. Parking pawl shaft | 67. Thrust bearing #6 |
| 49. Parking pawl shaft spring | 68. Overdrive clutch hub |
| 50. Parking roller support shaft | 69. Thrust bearing #5 |
| 51. Parking pawl | 70. Planetary reverse sun gear |

23D AUTOMATIC TRANSMISSION – Transmission


No. of Brake Discs and Plates

Brake	Brake Disc	Brake Plate
Low-reverse brake	6	5
Second brake	4	3

Main
Index

23
Index

23D
Index




TFA2176
10TJ051A

- 71. Snap ring
- 72. Second brake piston
- 73. Return spring
- 74. Pressure plate
- 75. Second brake disc
- 76. Second brake plate
- 77. Planetary carrier assembly
- 78. Snap Ring
- 79. Reaction plate
- 80. Snap ring
- 81. Low reverse brake disc
- 82. Low reverse brake plate
- 83. Pressure plate
- 84. Wave spring
- 85. Snap ring


- 86. One way clutch inner race
- 87. O-ring
- 88. Spring retainer
- 89. Return spring
- 90. Low reverse brake piston
- 91. Transfer drive gear
- 92. Snap ring
- 93. One way clutch
- 94. Seal ring
- 95. Needle bearing
- 96. Outer race
- 97. Spacer
- 98. Outer race
- 99. Transmission case

DISASSEMBLY**Caution**


1. Because the automatic transmission is manufactured from high-precision parts, sufficient care must be taken not to scratch or damage these parts during disassembly and reassembly.
2. The working area should be covered with a rubber mat to keep it clean at all times.
3. Do not wear any cloth gloves and do not use any rags during disassembly. Use nylon cloth if you need to use something.
4. Parts which have been disassembled should all be cleaned. Metal parts can be cleaned with normal detergent, but they should be dried completely using compressed air.
5. Clutch discs, plastic thrust plates and rubber parts should be cleaned with automatic transmission fluid (ATF) and keep them out of dust.
6. If the transmission body has been damaged, disassemble, flush and clean the cooler system also.



1. Remove the torque converter.
2. Use the dial gauge to measure the input shaft end play.
3. Remove each bracket.
4. Remove the oil level gauge.
5. Remove the eye bolt, gasket and the oil cooler feed tubes.




6. Remove the input shaft speed sensor and output shaft speed sensor.




7. Remove the manual control lever, and then remove the park/neutral position switch.

Caution


Make sure that the manual control lever installation nut is removed before removing the valve body.




8. Remove the speedometer gear.




9. Remove the valve body cover.



10. Remove the manual control shaft detent.



11. Disconnect the harness connectors of the valve body.




12. Remove the valve body mounting bolts (28 of).

13. Remove the fluid temperature sensor.

Caution


Make sure that the manual control lever and the park/neutral position switch are removed.




14. Remove the valve body, gasket and the steel balls (2 pieces).

Caution


Do not lose the steel balls (2 pieces).



15. Remove the snap ring, and then remove the solenoid valve harness.




16. Remove the strainer and the second brake retainer oil seal.



17. Remove each accumulator piston and spring.

No.	Name
1	For low-reverse brake
2	For underdrive clutch
3	For second brake
4	For overdrive clutch

Note: Label each accumulator piston and spring so that they can be reinstalled correctly.




18. Remove snap ring, reduction brake accumulator cover, spring and piston.

23D AUTOMATIC TRANSMISSION – Transmission


Main
Index

23
Index


23D
Index




19. Remove the manual control lever shaft roller.
20. Remove the manual control lever shaft and the parking pawl rod.




21. Remove the torque converter housing mounting bolts (20 pieces), and then remove the torque converter housing.



22. Remove the O-rings (2 pieces).



23. Remove the differential.




24. Remove the oil filter.

23D AUTOMATIC TRANSMISSION – Transmission


Main
Index

23
Index


23D
Index




25. Remove the oil pump pipe bolts and mounting bolts.
26. Install the special tools (MD998333) in the holes A.




27. Screw the special tool to remove the oil pump and pipe.
28. Remove the oil pump gasket and remove the pipe from the oil pump.




29. Remove thrust washer #1.




30. Hold the input shaft, and then remove the underdrive clutch.




31. Remove thrust bearing #2.




32. Remove the underdrive clutch hub.




33. Remove snap ring and the reduction brake piston cover.
34. Remove snap ring and then the reduction brake piston and snap ring.




35. Remove the parking pawl shaft and spring.




36. Pull out parking pawl roller support shafts out and remove the parking pawl and parking roller support.




37. Remove direct planetary carrier assembly.




38. Remove anchor plug and o-ring.




39. Remove direct clutch.



40. Remove reduction brake band.



41. Remove thrust bearing #11 and thrust race #12.




42. Remove the rear cover.


43. Remove the thrust race #8.

44. Remove the seal rings (4 pieces).


45. Remove the input shaft rear bearing.




46. Remove the O-rings.




47. Remove o-ring and then direct clutch accumulator piston and spring.




48. Remove the reverse and overdrive clutch and the thrust bearing #7.




49. Remove the overdrive clutch hub and the thrust bearing #6.




50. Remove thrust bearing #5.




51. Remove the planetary reverse sun gear.




52. Remove the snap ring.




53. Remove the second brake piston and the return spring.




54. Remove the pressure plate, brake discs and brake plates.




55. Remove the planetary carrier assembly.




56. Remove the snap ring.




57. Remove the reaction plate and brake disc.



58. Remove the snap ring.



59. Remove brake plates, brake discs and pressure plate.




60. Remove wave spring.

23D AUTOMATIC TRANSMISSION – Transmission


Main
Index

23
Index


23D
Index




61. Remove the snap ring using special tools.
62. Remove one way clutch race, o-ring, spring retainer, return spring and low reverse brake piston.




63. Remove the transfer drive gear fixing bolts.
64. After removing the transfer drive gear fixing bolts, turn gear 1/8 of turn and remove remaining bolts.



65. Remove the transfer drive gear.



66. Remove snap ring.




67. Remove one way clutch.
68. Remove seal rings.
69. Remove needle bearing.
70. Remove differential bearing outer race and spacer from converter housing.
71. Remove differential bearing outer race from transmission case.


REASSEMBLY

Caution

1. Never reuse the gasket, O-ring, oil seal, etc. Always replace with new ones when reassembling.
2. Never use grease other than blue or white petrolatum jelly.
3. Apply ATF to friction components, rotating parts, and sliding parts before installation. Immerse a new clutch disc or brake disc in ATF for at least two hours before assembling them.
4. Never apply sealant or adhesive to gaskets.
5. When replacing a bushing, replace the assembly which it belongs to.
6. Never use any cloth gloves or any rags during reassembly. Use nylon cloth or paper towels if you need to use something.
7. Change the oil in the cooler system.



1. Install transfer drive gear using special tool.




2. Tighten transfer drive gear fixing bolts (8 of) to specified torque.

23D AUTOMATIC TRANSMISSION – Transmission


Main
Index

23
Index


23D
Index




3. Install low-reverse brake piston, return spring and spring retainer.
4. Install new o-ring into the groove of the one way clutch inner race.
5. Check the position of identification notch of the one way clutch inner race and install one way clutch inner race onto the transfer drive gear bearing as the notch comes on A-A line.



6. Install snap ring using special tools.



7. Install wave spring onto low-reverse brake piston.




8. Install brake discs for low-reverse brake, brake plates and snap ring as shown in diagram.

Note: Do Not Install Pressure Plate.

Reference: Number of Brake Discs and Plates

Item	Quantity
Brake Discs	6
Brake Plates	5



9. Install the special tool on brake disc.
10. Install original reaction plate and snap ring.
11. Move the special tool and measure end play of reaction plate. Select the snap ring which was installed in 10. as it becomes the standard value and reassemble it.


Standard Value: 0 – 0.16 mm.

12. Install brake disc and brake plate for second brake.

Note: Do Not Install Pressure Plate.

Reference: Number of Brake Discs and Plates

Item	Quantity
Brake Discs	4
Brake Plates	3





13. Install the special tool.
14. Install return spring, second brake piston and snap ring.
15. Move the special tool and measure the amount of its end play. Select a pressure plate, which has the thickness for the specified amount, from the table below.

Reference: Standard value of end play for second brake 1.09 – 1.55 mm.

Pressure plate (second brake)

Amount of end play in mm.	Thickness mm.	Identification Code	Part Number
1.1 – 1.3	1.8	E	MD749425
1.3 – 1.5	2.0	D	MD749426
1.5 – 1.7	2.2	C	MD749427
1.7 – 1.9	2.4	B	MD749428
1.9 – 2.1	2.6	A	MD749429
2.1 – 2.3	2.8	0	MD749430






16. Turn the transmission over.
17. Install the special tool (MD998913) on dial gauge, move the special tool (MB991631 or MB991632) and measure the amount of its movement. Select a pressure plate, which has the thickness for the measured amount, from the table shown below.

Reference: Standard value of end play of low-reverse brake 1.65 – 2.11 mm.


Pressure plate (low-reverse brake)

Amount of end play in mm.	Thickness mm.	Identification Code	Part Number
1.0 – 1.2	1.6	F	MD759568
1.2 – 1.4	1.8	E	MD759425
1.4 – 1.6	2.0	D	MD759426
1.6 – 1.8	2.2	C	MD759427
1.8 – 2.0	2.4	B	MD759428
2.0 – 2.2	2.6	A	MD759429
2.2 – 2.4	2.8	0	MD759430
2.4 – 2.6	3.0	1	MD759431


18. Remove the parts which were installed in 7.–17.



19. Install needle bearing as shown on the figure.
20. Install the seal rings (2 of).



21. Install one way clutch with the identification mark up.



22. Install the snap ring.

Main
Index


23
Index

23D
Index

Main Index

23 Index

23D Index



TFA1683

IDENTIFICATION OF THRUST BEARINGS, THRUST RACES, AND THRUST WASHERS
 (All Units in mm.)

Symbol	O.D.	I.D.	Thickness	Part number
#1	59	47	1.8	MD754509
			2.0	MD754508
			2.2	MD754507
			2.4	MD753793
			2.6	MD753794
			2.8	MD753795
#2	49	34	3.6	MD756846

23D AUTOMATIC TRANSMISSION – Transmission

Symbol	O.D.	I.D.	Thickness	Part number
#3	57	38.5	4.12	MD758556
#4	55.4	38.5	3.3	MD761683
#5	57	38.5	4.12	MD758556
#6	57	38.5	4.12	MD758556
#7	59	37	2.8	MD754595
#8	48.9	37	1.6	MD707267
			1.7	MD759681
			1.8	MD723064
			1.9	MD754794
			2.0	MD707268
			2.1	MD754795
			2.2	MD723065
			2.3	MD754796
			2.4	MD724358
			2.5	MD754797
2.6	MD754798			
#9	78.5	60	2.5	MD753250
#10	54.6	43	3	MD753457
#11	58	40.7	4.2	MD762868
#12	80	60	2.5	MD753251

**Main
Index**

**23
Index**


**23D
Index**

23D AUTOMATIC TRANSMISSION – Transmission


Main
Index

23
Index


23D
Index




23. Install overdrive planetary carrier.
24. Install planetary carrier assembly.



25. Install planetary reverse sun gear.




26. Install wave spring on low reverse brake piston.




27. Install the pressure plate that was selected in 17. Then install brake discs and brake plates.

Reference: Number of Brake Discs and Plates


Item	Quantity
Brake Discs	6
Brake Plates	5
Pressure Plates	1




28. Install the snap ring.



29. Install the reaction plate.




30. Install the snap ring that was selected in 11.




31. Install the brake discs, brake plates and pressure plate that was selected in 15.

Reference: Number of Brake Discs and Plates


Item	Quantity
Brake Discs	4
Brake Plates	3
Pressure Plates	1



32. Install the return spring and second brake piston.




33. Install the snap ring.




34. Install thrust bearing #5.

Caution:
Install the thrust bearing in the correct direction.




35. Install over drive clutch hub and thrust bearing #6 on reverse & over drive clutch.

Caution:
Install the thrust bearing in the correct direction.



36. Install reverse, over drive clutch and thrust bearing #7.

Caution:
Install the thrust bearing in the correct direction.



37. Install the input shaft bearing into the rear cover using special tool.


38. Install seal rings (4 of).

23D AUTOMATIC TRANSMISSION – Transmission

Main
Index

23
Index

23D
Index




39. Use the following procedure to measure the under drive sun gear end play for the correct selection of thrust race #8.
- Install the thinnest thrust race #8 (thickness: 1.6mm, part number MD707267) on thrust bearing #7.
 - Install rear cover on transmission and tighten bolts to specified torque.
 - Turn transmission over and put the torque converter housing fixing side up.
 - Install under drive clutch hub on under drive sun gear.
 - Measure the end play of under drive sun gear and record the measured value.


Reference:

Standard Value: 0.25 – 0.45 mm.

- After the measurement, remove the parts which were installed in the procedure (a) – (d).




40. Install the direct clutch accumulator spring, piston and then o-ring.



41. Install the O-rings (6 of).
42. Select the thrust race which has the correct thickness for the measured value which was recorded in 39. and install it onto thrust bearing #7.


Measured Amount mm.	Thickness mm.	Part Number
0.3 – 0.4	1.6	MD707267
0.4 – 0.5	1.7	MD759681
0.5 – 0.6	1.8	MD723064
0.6 – 0.7	1.9	MD754794
0.7 – 0.8	2.0	MD707268
0.8 – 0.9	2.1	MD754795
0.9 – 1.0	2.2	MD723065
1.0 – 1.1	2.3	MD754796
1.1 – 1.2	2.4	MD724358
1.2 – 1.3	2.5	MD754797
1.3 – 1.4	2.6	MD754798




43. Squeeze out liquid gasket of 1.6mm. thickness and apply it to the places on rear cover as shown in diagram.

Reference:

Use Mitsubishi genuine sealant part # MD974421 or Equivalent.




44. Install the rear cover and tighten the bolts to the specified torque.




45. Install thrust race #12 and thrust bearing #11.

Note:

Install thrust bearing in the correct direction.




46. Tighten anchor plug and new o-ring temporarily and install reduction brake band and direct clutch at the same time.




47. Check that the direct clutch only turns in the direction shown in the diagram.

Note:


Reinstall one way clutch if it turns in opposite direction to direction shown in diagram.




48. Tighten anchor plug to specified torque.



49. Install direct planetary carrier assembly.






50. Install spring and reduction brake piston in transmission case and then the snap ring.




51. Adjust reduction brake piston using the following procedure.

- (a) Remove nut from reduction brake piston.
- (b) Install the special tool (MB991633 stopper) in order to stop the reduction piston rotating.
- (c) Using special tool (MB991633 socket) tighten and back off the adjusting rod to 10Nm twice. Tighten the adjusting rod to 5Nm and then back off the adjusting rod between 5 1/2 – 5 3/4 turns.
- (d) Install the nut on the adjusting rod without changing the rod position and tighten the nut using special tool to 19 ± 3 Nm.







52. Install the reduction brake piston cover and snap ring.




53. Install the parking pawl, spring and parking pawl shaft.



54. Install parking roller support and then parking roller support shafts (2 of).




55. Install the under drive clutch hub.




56. Install thrust bearing #2.

Note:


Install thrust bearing in the correct direction.




57. Hold input shaft and install under drive clutch.



58. Install thrust washer #1 (thickness: 1.8mm, part number MD754509) for the thinnest input shaft end play on under drive clutch retainer.



59. Install oil pipe on oil pump.




60. Install new oil pump gasket and oil pump using special tools. Install the pipe at the same time.

Note:

Do not reuse a gasket even if it has been tightened only once.


61. Tighten oil pump fixing bolts and pipe fixing bolt to the specified torque.




62. Measure the end play of the input shaft. Select thrust washer #1, which has the thickness to obtain the standard value, from the table on page 23D-36 and replace the thrust washer assembled in 58.

Reference:


Standard value: 0.70 – 1.45 mm.




63. Install oil filter.




64. Install the differential bearing outer race into the transmission case using special tools.




65. Install differential.



66. Install a piece of solder (approx. 10mm in length and 3mm in diameter) on the torque converter housing in the positions shown.




67. Install outer race using special tools.



68. Install the converter housing onto transmission without applying liquid gasket and tighten to the specified torque.

69. Loosen the bolts, remove converter housing and then take out the solder.




70. Measure the thickness of the crushed solder using a micrometer.


71. Select a spacer, [from spacer selection table](#), which is the measured thickness value plus the standard value of preload.

Reference:

Standard value: 0.045 – 0.105 mm preload.




72. Install the spacer selected in 70. into converter housing and tap into place using special tools.




73. Squeeze out liquid gasket of 1.6mm. thickness and apply it to the places on rear cover as shown in diagram.

Reference:

Use Mitsubishi genuine sealant part # MD974421 or Equivalent.




74. Install the converter housing and tighten the fixing bolts to the specified torque.




75. Install the manual control lever shaft and parking pawl rod.

76. Install the manual control lever shaft pin.



77. Install the reduction brake accumulator piston, spring, accumulator cover and snap ring.



78. Install a new seal ring on each accumulator piston.

Reference:


Pistons and seal rings are common parts.

79. Check the identification of the accumulator springs and insert them into each hole of transmission case.

Reference:

The identification of the accumulator springs are as in the following table and diagrams:

Name	Code	Identification Ink - Blue
Low-reverse brake	1	None
Under drive clutch	2	Half applied
Second brake	3	Fully applied
Over drive clutch	4	None




23D AUTOMATIC TRANSMISSION – Transmission


Main
Index

23
Index


23D
Index




80. Install the strainer and second brake retainer oil seal as shown in the diagram.




81. Install a new o-ring onto the groove of the solenoid valve harness connector.
82. Insert solenoid valve harness connector in to the hole from the inside of the transmission case as it faces the direction shown in the diagram. Then securely install the snap ring onto the connector groove.




83. Install the steel balls into each of 2 holes on the top of valve body (outside valve body).
84. Install valve body and gasket. Check that manual valve pin is in the detent plate groove of the manual control lever shaft.




85. Install oil temperature sensor.
86. Install valve body fixing bolts and tighten to the specified torque.
87. Connect connector to valve body.



Code	Fixing Position	Colour of Wire	Colour of Connector
1	Under drive solenoid valve	white,red, red	Black
2	Over drive solenoid valve	orange, red	Black
3	Low reverse solenoid valve	brown, yellow	Cream
4	Second solenoid valve	green,red, red	Cream
5	Damper clutch solenoid valve	blue, blue,yellow	Black
6	Reduction solenoid valve	orange,yel-low,yellow	Black
7	Oil temperature sensor	black, red	Black




88. Install the manual control shaft detent.




89. Apply liquid gasket to the valve body cover as shown in the diagram.

Reference:


Use Mitsubishi genuine sealant part # MD974421 or equivalent.




90. Install the valve body cover and tighten the fixing bolt to the specified torque.




91. Install speedometer gear.



92. Install the inhibitor switch and the manual control lever.



93. Install the input shaft speed sensor and output shaft speed sensor.



94. Install the eye bolt, a new gasket, and the oil cooler feed tube.
95. Install the oil dipstick.
96. Install the brackets.
97. Install the torque converter, and secure it so that the shown dimension (A) meets the reference value.

Reference:


Standard value: approx. 9.4 mm


Caution

Apply ATF to the oil pump drive hub before installing the torque converter. Be careful not to damage the oil seal lip when installing the torque converter.

OIL PUMP

DISASSEMBLY AND REASSEMBLY

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA2204

Disassembly steps

- ▶B◀ 1. O-ring
- ▶A◀ 2. Seal ring
- ▶A◀ 3. Oil seal
- ▶A◀ 4. Oil pump assembly


REASSEMBLY SERVICE POINTS

▶A◀ OIL SEAL INSTALLATION

1. Install oil seal using special tool.

▶B◀ O-RING INSTALLATION


2. Install new o-ring to the outside groove of the oil pump, apply ATF, blue or white petroleum jelly to the outside surface of the o-ring.




TFA1431

UNDERDRIVE CLUTCH AND INPUT SHAFT

DISASSEMBLY AND REASSEMBLY



 Lubricate all internal parts with automatic transmission fluid during reassembly.

TFA2205


Number of clutch discs and plates

Clutch disc	Clutch plate	Clutch reaction plate
4	4	1

Disassembly steps

1. Snap ring
2. Input shaft
3. Seal ring
4. Snap ring
5. Clutch reaction plate
6. Clutch disc
7. Clutch plate
8. Snap ring


9. Spring retainer
10. D-ring
11. Return spring
12. Underdrive clutch piston
13. D-ring
14. D-ring
15. Underdrive clutch retainer



DISASSEMBLY SERVICE POINT

◀A▶ SNAP RING REMOVAL

1. Remove snap ring using special tools.




REASSEMBLY SERVICE POINTS

▶A◀ D-RING INSTALLATION

1. Apply ATF, blue petrolatum jelly or white Vaseline to the D-ring, and install it carefully.

▶B◀ SNAP RING INSTALLATION

1. Install snap ring using special tools.




▶C◀ CLUTCH PLATE/CLUTCH DISC/CLUTCH REACTION PLATE INSTALLATION


1. Wave type clutch discs are used. Put two clutch discs together and gradually slide them around, if there is a gap visible between them, they are wave type clutch discs.

Caution:


Immerse the clutch disc in ATF before assembling it.



2. Align the spaces between the teeth (part A) of clutch plate, clutch discs and clutch reaction plate to the outer circumference hole (part B) of the under drive clutch retainer and assemble.



3. Install clutch reaction plate in the direction shown in diagram.




▶D◀ SNAP RING INSTALLATION



1. Install snap ring
2. When measuring the clearance, use the special tool to press the clutch reaction plate evenly.
3. Check that the clearance between the snap ring and the clutch reaction plate is within the standard value. If not within the standard value, select a snap ring to adjust.

Standard value:
1.7 ± 0.1 mm

REVERSE AND OVERDRIVE CLUTCH

DISASSEMBLY AND REASSEMBLY

 Lubricate all internal parts with automatic transmission fluid during reassembly.










































TFA2208


Number of over drive clutch discs and plates

Clutch disc	Clutch plate	Clutch reaction plate
4	3	1

Disassembly steps

-   1. Snap ring
-   2. Clutch reaction plate
-   3. Clutch disc
-   4. Clutch plate
-   5. Snap ring
-   6. Clutch reaction plate
-   7. Clutch disc
-   8. Clutch plate
-   9. Clutch pressure plate
-   10. Snap ring

-  11. Spring retainer
-   12. D-ring
-   13. D-ring
-   14. Overdrive clutch piston
-   15. D-ring
-   16. Reverse clutch piston
-   17. D-ring
-   18. Reverse clutch retainer
-   19. D-ring
-   20. D-ring



DISASSEMBLY SERVICE POINT


◀A▶ SNAP RING REMOVAL

1. Remove snap ring using special tools.

REASSEMBLY SERVICE POINTS


▶A◀ D-RING INSTALLATION

1. Apply ATF, blue petroleum jelly or white Vaseline to D-ring, and install carefully.




▶B◀ REVERSE CLUTCH PISTON INSTALLATION

1. Align the outer circumference holes (parts A and B) of the reverse clutch piston and the reverse clutch retainer to assemble them.



▶C◀ SNAP RING INSTALLATION


1. Use the special tool to install the snap ring.



2. Push evenly on circumference of return spring retainer firmly (49N {5kgf}).
3. Check that the clearance between the snap ring and the return spring retainer is within the standard value. If not within the standard value, select a snap ring to adjust to standard value.


Reference:

Standard value: 0 – 0.09 mm



►D◄ CLUTCH PLATE/CLUTCH DISC/CLUTCH REACTION PLATE INSTALLATION


1. Wave type clutch discs are used. Put two clutch discs together and gradually slide them around, if there is a gap visible between them, they are wave type clutch discs.




2. Align the spaces between the teeth (part A) of clutch pressure plate, clutch plate, clutch disc, and clutch reaction plate to the outer circumference hole (part B) of reverse clutch piston and assemble.

Caution

Immerse the clutch disc in ATF before assembling the clutch disc.



3. Install the clutch reaction plate in the direction shown in the diagram.




►E◄ SNAP RING INSTALLATION

1. Install snap ring.
2. When measuring the clearance, use the special tool to press the clutch reaction plate evenly. Check that the clearance between the snap ring and the clutch reaction plate is within the standard value. If not within the standard value, select a snap ring to adjust.


Reference:

Standard value: 1.7 ± 0.1 mm



►F◄ CLUTCH PLATE/CLUTCH DISC/CLUTCH REACTION PLATE INSTALLATION


1. Wave type clutch discs are used. Put two clutch discs together and gradually slide them around, if there is a gap visible between them, they are wave type clutch discs.




2. Align the space between the teeth (part A) of the clutch pressure plate, clutch plate, clutch disc and clutch reaction plate to the outer circumference hole (part B) of the reverse clutch piston and assemble.

Caution

Immerse the clutch disc in ATF before assembling the clutch disc.



3. Install the clutch reaction plate in the shown direction.



▶G◀ SNAP RING INSTALLATION


1. Install snap ring.
2. When measuring the clearance, press the clutch reaction plate by the weight of $1471 \pm 50\text{N}$ ($150 \pm 5\text{kgf}$) evenly. Check that the clearance between the snap ring and the clutch reaction plate is within the standard value. If not within the standard value, select a snap ring to adjust to standard value.


Reference:

Standard value: $1.6 \pm 0.1\text{mm}$

DIRECT CLUTCH










DISASSEMBLY AND REASSEMBLY


 Lubricate all internal parts with automatic transmission fluid during reassembly.




TFA2212

Disassembly steps

-  1. Snap ring
-  2. Clutch reaction plate
-  3. Clutch disc
-  4. Clutch plate
-   5. Snap ring
-  6. Spring retainer
-  7. D-ring
- 8. Return spring
- 9. Direct clutch piston
-  10. D-ring


-  11. D-ring
- 12. Direct clutch retainer



DISASSEMBLY SERVICE POINT

◀A▶ SNAP RING REMOVAL

1. Remove snap ring using special tools.




REASSEMBLY SERVICE POINTS

▶A◀ D-RING INSTALLATION

1. Apply ATF, blue petroleum jelly or white Vaseline to D-ring, and install carefully.

▶B◀ SNAP RING INSTALLATION

1. Use the special tools to install the snap ring.




▶C◀ CLUTCH PLATE, CLUTCH DISC AND CLUTCH REACTION PLATE INSTALLATION


1. Align the spaces between the teeth (part A) of clutch plate, clutch disc and clutch reaction plate to the outer circumference hole (part B) of direct clutch retainer and assemble.

Caution

Immerse the clutch disc in ATF before assembling the clutch disc.



2. Install the clutch reaction plate in the direction shown in the diagram.



▶D◀ SNAP RING INSTALLATION


1. Install snap ring.
2. When measuring the clearance, press the return spring retainer by the weight of 49 N (5kgf) evenly. Check that the clearance between the snap ring and the return spring retainer is within the standard value. If not within the standard value, select a snap ring to adjust.


Reference:

Standard value: 1.1 ± 0.1 mm

PLANETARY CARRIER ASSEMBLY

DISASSEMBLY AND REASSEMBLY

 Lubricate all internal parts with automatic transmission fluid during reassembly.




TFA2042

Disassembly steps

- ▶B◀ 1. Stopper plate
- ▶B◀ 2. One-way clutch
- ▶B◀ 3. Snap ring
- ▶A◀ 4. Output planetary carrier
- ▶A◀ 5. Thrust bearing #3
- ▶A◀ 6. Under drive sun gear
- ▶A◀ 7. Thrust bearing #4
- ▶A◀ 8. Snap ring
- ▶A◀ 9. Over drive planetary carrier
- ▶A◀ 10. Over drive annulus gear

Main
Index23
Index23D
Index




REASSEMBLY SERVICE POINTS

►A◄ THRUST BEARINGS #3 & #4 INSTALLATION

1. Install thrust bearing #3 and #4 in the position shown in the diagram.

Reference:

Install thrust bearings in the correct direction.



►B◄ ONE WAY CLUTCH INSTALLATION

1. Insert one way clutch into over drive annulus gear as the arrow points to output planetary carrier side.

Caution:

Install one way clutch in the correct direction.


LOW-REVERSE BRAKE


DISASSEMBLY AND REASSEMBLY

Main
Index

23
Index

23D
Index

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA2214

Disassembly steps




1. D-ring
2. D-ring
3. Low-reverse brake piston


REASSEMBLY SERVICE POINT

▶A◀ D-RING INSTALLATION

Apply ATF, blue petrolatum jelly or white petrolatum jelly to D-ring, and install carefully.

SECOND BRAKE**DISASSEMBLY AND REASSEMBLY**Main
Index23
Index23D
Index

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA2215

Disassembly steps


- ▶A◀ 1. Second brake retainer
- ▶A◀ 2. D-ring
- ▶A◀ 3. Second brake piston
- ▶A◀ 4. D-ring


REASSEMBLY SERVICE POINT**▶A◀ D-RING INSTALLATION**

Apply ATF, blue petrolatum jelly or white Vaseline to D-ring, and install carefully.

DIRECT PLANETARY CARRIER

DISASSEMBLY AND REASSEMBLY


 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1716

Disassembly steps

- | | | | |
|---------|----------------------|---------|--|
| ◀A▶ ▶D▶ | 1. Lock nut | ◀B▶ ▶C▶ | 6. Parking gear |
| | 2. Roller bearing | ◀C▶ ▶B▶ | 7. Taper roller bearing |
| | 3. Thrust bearing #9 | | 8. Transfer driven & direct annulus gear |
| | 4. Thrust race #10 | ◀D▶ ▶A▶ | 9. Taper roller bearing |
| ◀B▶ ▶C▶ | 5. Output gear | | 10. Direct planetary carrier |




TFA1717


DISASSEMBLY SERVICE POINTS

◀A▶ LOCK NUT REMOVAL

1. Remove stake from lock nut.




2. Remove lock nut using special tool.




◀B▶ **OUTPUT GEAR / PARKING GEAR REMOVAL**

1. Remove output gear and parking gear using special tools.




◀C▶ **TAPER ROLLER BEARING / TRANSFER DRIVEN GEAR REMOVAL**

1. Support transfer driven gear as shown in diagram.
2. Push directly on planetary carrier shaft and pull taper roller bearing and transfer driven gear off.



◀D▶ **TAPER ROLLER BEARING REMOVAL**


1. Remove taper roller bearing using special tools.



ASSEMBLY SERVICE POINTS


▶A▶ **TAPER ROLLER BEARING INSTALLATION**

1. Install taper roller bearing using special tools.




►B◄ TAPER ROLLER BEARING INSTALLATION

1. Install transfer driven gear and taper roller bearing using special tools.




►C◄ OUTPUT GEAR / PARKING GEAR INSTALLATION

1. Install output gear and parking gear using special tools.



►D◄ LOCK NUT INSTALLATION


1. Apply ATF to new lock nut and tighten it to the specified torque. Then loosen it one turn and tighten it again to the specified torque.




2. Stake the new lock nut in two places to prevent it from turning.

DIFFERENTIAL









DISASSEMBLY AND REASSEMBLY






 Lubricate all internal parts with automatic transmission fluid during reassembly.




10AE006N

Disassembly steps

-   1. Differential drive gear
-   2. Taper roller bearings
-   3. Lock pin
-   4. Pinion shaft

-  5. Pinions
-  6. Washers
-  7. Side gears
-  8. Spacers
-  9. Differential case



DISASSEMBLY SERVICE POINTS

TAPER ROLLER BEARING REMOVAL

1. Remove taper roller bearing using special tools.

REASSEMBLY SERVICE POINTS




▶A◀ SPACER, SIDE GEAR, WASHER, PINION, PINION SHAFT INSTALLATION

1. Install the spacers to the back side of the side gears, and then assemble the side gears into the differential case.

NOTE

Select the medium size spacer [0.93 – 1.00 mm] when assembling a new side gear.

2. Attach the washers to the back side of the pinions, engage the pinions simultaneously to the side gears, and settle the gears to the specified position by turning.



3. Insert the pinion shaft.

4. Measure the backlash between the side gears and pinions.


Standard value:

0.025 – 0.150 mm

5. If not within the standard value, change a spacer and measure the backlash again.


NOTE

Adjust so that both backlashes are equal.




▶B◀ LOCK PIN INSTALLATION

1. Install the chamfered side of the lock pin first, as per diagram.



►C◄ **TAPER ROLLER BEARING INSTALLATION**

1. Install the taper roller bearings using special tools.




►D◄ **DIFFERENTIAL DRIVE GEAR INSTALLATION**

1. Apply ATF to the bolts and tighten to the specified torque in the sequence shown in the diagram.

VALVE BODY

DISASSEMBLY AND REASSEMBLY

Main Index
23 Index
23D Index





TFA1727

Disassembly steps

- | | |
|--|--|
| <ul style="list-style-type: none"> ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ ▶A▶▶C▶ | <ol style="list-style-type: none"> 1. Solenoid valve support 2. Underdrive solenoid valve 3. Second solenoid valve 4. Torque converter clutch control solenoid valve 5. Overdrive solenoid valve 6. Low-reverse solenoid valve 7. Reduction solenoid valve 8. Manual valve 9. Cover 10. Plate 11. Outside valve body assembly 12. Steel ball (orifice check ball) 13. Spring 14. Plate 15. Damping valve 16. Damping valve spring 17. Steel ball (line relief) 18. Spring 19. Steel ball (orifice check ball) 20. Spring 21. Inside valve body assembly |
|--|--|

23D AUTOMATIC TRANSMISSION – Valve Body

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1728

- | | |
|---|--|
| <ul style="list-style-type: none"> 22. Roller 23. Damper clutch control valve sleeve 24. Damper clutch control valve 25. Damper clutch control valve spring 26. Plate 27. Screw 28. Regulator valve spring 29. Regulator valve 30. Plate 31. Fail-safe valve A sleeve 32. Fail-safe valve A2 33. Fail-safe valve A spring 34. Fail-safe valve A1 35. Plate 36. Plug 37. Torque converter valve 38. Torque converter valve spring 39. Plate 40. Fail-safe valve B sleeve 41. Fail-safe valve B 42. Inside valve body 43. Roller 44. Overdrive pressure control valve sleeve 45. Overdrive pressure control valve 46. Overdrive pressure control valve spring 47. Roller 48. Low–reverse pressure control valve sleeve | <ul style="list-style-type: none"> 49. Low–reverse pressure control valve 50. Low–reverse pressure control valve spring 51. Roller 52. Reduction pressure control valve sleeve 53. Reduction pressure control valve 54. Reduction pressure control valve spring 55. Plate 56. Plug 57. Switch valve 58. Roller 59. Underdrive pressure control valve sleeve 60. Underdrive pressure control valve 61. Underdrive pressure control valve spring 62. Roller 63. Second pressure control valve sleeve 64. Second pressure control valve 65. Second pressure control valve spring 66. Plate 67. Fail-safe valve C sleeve 68. Fail-safe valve C 69. Outside valve body |
|---|--|

Main Index
23 Index
23D Index

DISASSEMBLY SERVICE POINT

◀A▶ SOLENOID VALVE REMOVAL



NOTE

1. Before removing the solenoid valves, identify each solenoid valve with white paint or similar to facilitate reassembly.
2. Store each solenoid valve separately, according to its location, to avoid incorrect reassembly.

REASSEMBLY SERVICE POINTS


▶A◀ SPRING/STEEL BALL/DAMPING VALVE/DAMPING VALVE SPRING INSTALLATION

1. Install steel balls, springs and damping valve in the positions shown in the diagram.



▶B◀ SPRING/STEEL BALL INSTALLATION

1. Install spring and steel balls in the positions shown in the diagram.




▶C◀ SOLENOID VALVE INSTALLATION


1. Install the solenoid valves by referring to the marks made during disassembly.

No.	Name
1	Underdrive solenoid valve
2	Second solenoid valve
3	Damper clutch control solenoid valve
4	Overdrive solenoid valve
5	Low–reverse solenoid valve
6	Reduction solenoid valve

REDUCTION BRAKE PISTON

DISASSEMBLY AND REASSEMBLY

 Lubricate all internal parts with automatic transmission fluid during reassembly.



Main
Index

23
Index

23D
Index

TFA1730

Disassembly steps

1. Nut
2. Adjusting rod
3. Reduction brake piston
4. Seal ring


SPEEDOMETER GEAR





DISASSEMBLY AND REASSEMBLY

Main
Index

23
Index

23D
Index

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFM0593


Disassembly steps


1. E-clip
2. Speedometer driven gear
3. O-ring
4. Sleeve

DRIVE SHAFT OIL SEAL

DISASSEMBLY AND REASSEMBLY

Main Index
23 Index
23D Index

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1731


Disassembly steps


- ▶ **A** ◀ 1. Oil seal
- ▶ **B** ◀ 2. Torque converter housing
- ▶ **B** ◀ 3. Oil seal
- ▶ **B** ◀ 4. Transmission case

REASSEMBLY SERVICE POINT

▶ **A** ◀ OIL SEAL INSTALLATION

- 1. Install oil seal using special tool.





►B◄ OIL SEAL INSTALLATION

1. Install oil seal using special tool.

Main
Index

23
Index

23D
Index